

http://en.wikipedia.org/wiki/American_wire_gauge

580 captures
16 May 2014 - 26 Jun 2020

WIKIPEDIA
The Free Encyclopedia

Navigation
Main page
Contents
Featured content
Current events
Random article
Donate to Wikipedia
Wikimedia Shop

Interaction
Help
About Wikipedia
Community portal
Recent changes
Contact page

Tools
What links here
Related changes
Upload file
Special pages
Permanent link
Page information
Wikidata item
Cite this page

Print/export
Create a book
Download as PDF
Printable version

Languages
العربية
Deutsch
Español
Français
Galego
한국어
Հայերեն
Italiano
Nederlands
日本語
Polski
Português
Русский
Slovenčina
Svenska
Українська
中文

[Edit links](#)

American wire gauge

From Wikipedia, the free encyclopedia

"AWG" redirects here. For other uses, see AWG (disambiguation).

American wire gauge (**AWG**), also known as the **Brown & Sharpe wire gauge**, is a standardized **wire gauge** system used since 1857 predominantly in North America for the diameters of round, solid, nonferrous, electrically conducting wire.^[1] The cross-sectional area of each gauge is an important factor for determining its **current-carrying capacity**.

The steel industry does not use AWG and prefers a number of other wire gauges.^[*citation needed*] These include Washburn & Moen (or W&M) Wire Gauge, US Steel Wire Gauge, and Music Wire Gauge (see *Piano wire*).

Increasing gauge numbers denote decreasing wire diameters, which is similar to many other non-metric gauging systems. This gauge system originated in the number of **drawing operations** used to produce a given gauge of wire. Very fine wire (for example, 30 gauge) required more passes through the **drawing dies** than did 0 gauge wire. Manufacturers of wire formerly had proprietary wire gauge systems; the development of standardized wire gauges rationalized selection of wire for a particular purpose.

The AWG tables are for a single, solid, round conductor. The AWG of a stranded wire is determined by the total cross-sectional area of the conductor, which determines its current-carrying capacity and **electrical resistance**. Because there are also small gaps between the strands, a stranded wire will always have a slightly larger overall diameter than a solid wire with the same AWG.

AWG is also commonly used to specify **body piercing jewelry sizes** (especially smaller sizes), even when the material is not metallic.^[2] However, metallic **hypodermic needles** and blunt needles are usually specified in terms of **Needle gauge**.

Contents

- Formula
 - 1.1 Rules of thumb
- Tables of AWG wire sizes
- Stranded wire AWG sizes
- Nomenclature and abbreviations in electrical distribution
- Pronunciation
- See also
- References
- Further reading
- External links

Formula [*edit*]

By definition, No. 36 AWG is 0.005 inches in diameter, and No. 0000 is 0.46 inches in diameter. The ratio of these diameters is 1:92, and there are 40 gauge sizes from No. 36 to No. 0000, or 39 steps. Because each successive gauge number increases diameter by a constant multiple, diameters vary geometrically. Any two successive gauges (e.g. A & B) have diameters in the ratio (dia. B ÷ dia. A) of $\sqrt[39]{92}$ (approximately 1.12293), while for gauges two steps apart (e.g. A, B & C), the ratio of the C to A is about 1.12293² = 1.26098. The diameter of a No. *n* AWG wire is determined, for gauges smaller than 00 (36 to 0), according to the following formula:

$$d_n = 0.005 \text{ inch} \times 92^{\frac{36-n}{39}} = 0.127 \text{ mm} \times 92^{\frac{36-n}{39}}$$

(see below for gauges larger than No. 0 (i.e. No. 00, No. 000, No. 0000).) or equivalently

$$d_n = e^{-1.12436-0.11594n} \text{ inch} = e^{2.1104-0.11594n} \text{ mm}$$

The gauge can be calculated from the diameter using

$$n = -39 \log_{92} \left(\frac{d_n}{0.005 \text{ inch}} \right) + 36 = -39 \log_{92} \left(\frac{d_n}{0.127 \text{ mm}} \right) + 36$$

and the cross-section area is

$$A_n = \frac{\pi}{4} d_n^2 = 0.000019635 \text{ inch}^2 \times 92^{\frac{36-n}{19.5}} = 0.012668 \text{ mm}^2 \times 92^{\frac{36-n}{19.5}}$$

The standard **ASTM B258 - 02(2008) Standard Specification for Standard Nominal Diameters and Cross-Sectional Areas of AWG Sizes of Solid Round Wires Used as Electrical Conductors** defines the ratio between successive sizes to be the 39th root of 92, or approximately 1.1229322.^[4] ASTM B 258-02 also dictates that wire diameters should be tabulated with no more than 4 significant figures, with a resolution of no more than 0.0001 inches (0.1 mils) for wires larger than No. 44 AWG, and 0.00001 inches (0.01 mils) for wires No. 45 AWG and smaller. Sizes with multiple zeros are successively larger than No. 0 and can be denoted using "number of zeros/0", for example 4/0 for 0000. For an *m*/0 AWG wire, use *n* = −(*m*−1) = 1−*m* in the above formulas. For instance, for No. 0000 or 4/0, use *n* = −3.

Rules of thumb [*edit*]

The sixth power of this ratio is very close to 2,^[5] which leads to the following rules of thumb:

- When the *diameter* of a wire is doubled, the AWG will decrease by 6. (e.g., No. 2 AWG is about twice the diameter of No. 8 AWG.)
- When the *cross-sectional area* of a wire is doubled, the AWG will decrease by 3. (e.g., Two No. 14 AWG wires have about the same cross-sectional area as a single No. 11 AWG wire.)

A decrease of ten gauge numbers, for example from No. 10 to 1/0, multiplies the area and weight by approximately 10 and reduces the resistance by a factor of approximately 10. **Aluminum wire** has a conductivity of approximately 61% of copper, so an aluminum wire has nearly the same resistance as a **copper wire** 2 AWG sizes smaller. (Which has 62.9% of the area.)

Tables of AWG wire sizes [*edit*]

The table below shows various data including both the resistance of the various wire gauges and the allowable current (**ampacity**) based on plastic insulation. The diameter information in the table applies to *solid* wires. **Stranded wires** are calculated by calculating the equivalent **cross sectional copper area**. Fusing current (melting wire) is estimated based on 25°C ambient temperature. The table below assumes DC, or AC frequencies equal to or less than 60 Hz, and does not take *skin effect* into account. Turns of wire is an upper limit for wire with no insulation.

AWG	Diameter		Turns of wire, no insulation		Area		Copper resistance ^[6]		NEC copper wire ampacity with 60/75/90 °C insulation (A) ^[7]	Approx. metric equivalents	Fusing current, copper ^{[8][9]}		
	(in)	(mm)	(per in)	(per cm)	(kcmil)	(mm ²)	(Ω/km)	(Ω/ft)			Preece, −10 s	Onderdonk,	
												1 s	32 ms
0000 (4/0)	0.4600*	11.684*	2.17	0.856	212	107	0.1608	0.04901	195 / 230 / 260		3.2 kA	33 kA	182 kA
000 (3/0)	0.4096	10.405	2.44	0.961	168	85.0	0.2028	0.06180	165 / 200 / 225		2.7 kA	26 kA	144 kA
00 (2/0)	0.3648	9.266	2.74	1.08	133	67.4	0.2557	0.07793	145 / 175 / 195		2.3 kA	21 kA	115 kA

Pronunciation [edit]

AWG is colloquially referred to as *gauge* and the zeros in large wire sizes are referred to as *ought* /ɔːt/. Wire sized 1 AWG is referred to as "one gauge" or "No. 1" wire; similarly, smaller diameters are pronounced "x gauge" or "No. X" wire, where x is the positive integer AWG number. Consecutive AWG wire sizes larger than No. 1 wire are designated by the number of zeros:

- No. 0, typically written 1/0 and is referred to as "one ought" wire
- No. 00, typically written 2/0 and is referred to as "two ought" wire
- No. 000, typically written 3/0 and is referred to as "three ought" wire,

and so on. ^[10]

See also [edit]

- IEC 60228 for international standard wire sizes
- Standard wire gauge (former British standard)
- A chart comparing all known wire gauges (PDF)
- Number 8 wire, a term used in the New Zealand vernacular
- Stubs Iron Wire Gauge
- Electric power distribution
- Electrical wiring
- Cable
- Power cord
- Extension cord
- Magnet wire
- Body jewelry sizes

References [edit]

- ↑ ASTM Standard B 258-02, *Standard specification for standard nominal diameters and cross-sectional areas of AWG sizes of solid round wires used as electrical conductors*, ASTM International, 2002
- ↑ SteelNavel.com Body Piercing Jewelry Size Reference — illustrating the different ways that size is measured on different kinds of jewelry
- ↑ The logarithm to the base 92 can be computed using any other logarithm, such as common or natural logarithm, using log₉₂ x = (log x)/(log 92).
- ↑ ASTM Standard B 258-02, page 4
- ↑ The result is roughly 2.0050, or one-quarter of one percent higher than 2
- ↑ Figure for solid copper wire at 68 °F, computed based on 100% IACS conductivity of 58.0 MS/m, which agrees with multiple sources:
 - http://www.eskimo.com/~billb/tesla/wire1.txt
 - Mark Lund, PowerStream Inc., *American Wire Gauge table and AWG Electrical Current Load Limits* , retrieved 2008-05-02 (although the ft/m conversion seems slightly erroneous)
 - Belden Master Catalog , 2006, although data from there for gauges 35 and 37–40 seems obviously wrong.High-purity oxygen-free copper can achieve up to 101.5% IACS conductivity; e.g., the Kanthal conductive alloys data sheet lists slightly lower resistances than this table.
- ↑ NFPA 70 National Electrical Code 2008 Edition . Table 310.16 page 70-148, *Allowable ampacities of insulated conductors rated 0 through 2000 volts, 60°C through 90°C, not more than three current-carrying conductors in raceway, cable, or earth (directly buried) based on ambient temperature of 30°C*. Extracts from NFPA 70 do not represent the full position of NFPA and the original complete Code must be consulted. In particular, the maximum permissible overcurrent protection devices may set a lower limit.
- ↑ Computed using equations from H. Wayne Beaty; Donald G. Fink, eds. (2007), *The Standard Handbook for Electrical Engineers* (15th ed.), McGraw Hill, pp. 4–25, ISBN 0-07-144146-8
- ↑ Douglas Brooks (December 1998), "Fusing Current: When Traces Melt Without a Trace" , *Printed Circuit Design* **15** (12): 53
- ↑ Glossary of Power Terms | Event Solutions

Further reading [edit]

- Donald G. Fink and H. Wayne Beaty, *Standard Handbook for Electrical Engineers, Eleventh Edition*, McGraw-Hill, New York, 1978, ISBN 0-07-020974-X, page 4-18 and table 4-11.

External links [edit]

- How to Gauge Traces
- Conversion and calculation of cable diameter to AWG and vice versa
- Table of wire resistivities for bigger gauge (insulation included)
- Bare copper wire AWG NEMA/IEC metric standard sizes
- Reference for conversions and maximum safe current loads
- Glossary of common Electrical Terms & Reference Chart

Categories: Wire gauges | Customary units of measurement in the United States

This page was last modified on 18 June 2014 at 08:13.

Text is available under the Creative Commons Attribution-ShareAlike License; additional terms may apply. By using this site, you agree to the Terms of Use and Privacy Policy. Wikipedia® is a registered trademark of the Wikimedia Foundation, Inc., a non-profit organization.

Privacy policy About Wikipedia Disclaimers Contact Wikipedia Developers Mobile view

